

Pre-fabricated Knee Extension Brace

How to measure for a Pre-fabricated Knee Brace:

1. Position leg in maximum extension.
2. A circumference measurement should be taken around the leg at each level.

Level A - is located 9.5 inches (25 cm) above joint center.

Level B - is located at the joint center.

Level C - is located 9.5 inches (25 cm) below joint center.

| Measurement for Pre-fabricated Knee Extension Brace | | | |
|--|---------------|--------------|-------------|
| | Circumference | | |
| | | Inches | Centimeters |
| Small | A | 12.75 - 16.5 | 32.4 - 41.9 |
| | B | 11.75 - 14.5 | 29.8 - 36.9 |
| | C | 8 - 11.75 | 20.3 - 29.8 |
| Medium | A | 18 - 21 | 45.7 - 53.3 |
| | B | 15 - 17 | 38.1 - 43.2 |
| | C | 9.5 - 12.5 | 24.1 - 31.8 |
| Large | A | 21 - 24 | 53.3 - 61 |
| | B | 17 - 20 | 43.2 - 50.8 |
| | C | 12.75 - 16.5 | 32.4 - 41.9 |

